





Version: S1900-1903



# Windproof Arc Lighter

## Instruction

Thanks for your purchase, please read the instruction before your first use.



## Use

- 1) Push the Safety Switch ON, electrodes come out, then press the ignition button and hold up the arc-flame to light;
- 2) Get the arc-flame close to objects you want to ignite, no need to directly touch on the electrodes.
- 3) Push the Safety Switch OFF if you finish lighting work.

\*\*\* Long press the activation button for over 10 seconds at one ignition time, the power will be cut off automatically for safety and prevent product from damage.\*\*\*

## Charging

- 1) Before your first use, to ensure sufficient power please charge it for 1~2 hours;
- 2) In low power situation, soft LED light in-set with ignition button will give you notification. You can charge it by using your USB charger, PC or Power bank, anyway, it is universal in charging.

## Warm-tip

Keep your electrodes/contacts clean, we pack a small brush in box for your convenience.

## Attention

1. Place the product out of the reach of children.
2. Do not contact the arc sparks with your fingers or metal to avoid any injury.
3. Do not place the product into water or other liquids, or it will cause a short circuit.
4. Please disconnect the power immediately after fully charged (1 - 1.5h fully charged), do not leave the arc lighter connected to the power source because overcharging will shorten the battery life.
5. Please charge it before the battery is completely out of juice to extend the battery life.
6. Do not press the activation button for more than 10 seconds at a time to last the product's life.
7. Do not disassemble the arc lighter to avoid damaging the product or causing personal injury.

## Q&A

Q: Can't be charged even though it works well in low battery condition.

A: Please charge it via another micro USB 2.0 cable to check if the cord goes bad. If still can't be charged, please contact us without hesitation.

Q: Lighter is full charged but it doesn't work, no arc created from the electrodes.

A: Please take a tissue or little brush to clean the contacts of electrodes. If still doesn't work, please send email to us.

For more Q&A, please visit [sipoe.com](http://sipoe.com) for help

## Warranty

We offer 30-day money back and 18-month product warranty for defective replacement. Also you can register it for a 2-year extended warranty.

Scan QR code to View Warranty



Direct visit: <https://sipoe.com/register-product>

## Support

Email: [support@sipoe.com](mailto:support@sipoe.com)

Text us on Messenger by entering: [m.me/sipoe.fans](https://m.me/sipoe.fans)

Instagram: [@thesipoe](https://www.instagram.com/thesipoe)

Facebook: [facebook.com/sipoe.fans](https://www.facebook.com/sipoe.fans)

<https://sipoe.com/contact>